



We are incredibly grateful for your purchase of Chirpie∞, our Personal Safety Alarm! We are committed to creating safer communities for women, children, and vulnerable individuals, and with your help, we are closer to accomplishing this mission.

When to use it

When you're in a situation that causes alarm, and you need to alert those around you for assistance or to scare away potential assailants, Chirpie $^{\infty}$ is the ideal answer.

A few scenarios where this could be useful include:

- 1. If you suspect you are being followed while walking alone.
- 2. You spot a potentially unsafe situation nearby, for example a suspicious person approaching children, and want to draw attention and scare away the attacker.
- 3. You require immediate assistance but cannot reach people with your voice.

What it does

When activated, Chirpie∞ will emit a loud alarm noise and the built-in light will start flashing, both of which will continue until deactivated. The alarm duration is expected to last up to 90 minutes with full power.

How to use it

- 1: Please remove the insulating sheet before using Chirpie∞.
 - To activate Chirpie∞, simply pull out the pin.
 - To stop the alarm, simply insert the pin back into the device.
- 2: Press in the side button to turn on the flashlight, let go to turn off the flashlight.
- 3: Low battery indicator will flash 10 times if pin pulled out or light button pressed.



Charging Method: USB C Charging time: within 1 hour Battery capacity:200mAh/3.7V

Made in China

#StaySafeWithChirpie

P: 03 9588 0392

W: safelife.com.au E: sales@safelife.com.au

