



# Safe- Life Pendant Docking Station

## M-DOCK FAQ'S

**Q. How do I know that I have power to the charger?**

**R. If the plug is inserted into a power source correctly a dim Red Led will appear at the front of the dock. Once the Safelife pendant is inserted correctly the light will get brighter.**

**Q. Can I over charge the pendant?**

**R. You cannot over charge the pendant despite how long it is in charge it will just hold the maximum charge, just as a mobile phone would when charged over- night.**

**Q. Can you replace the battery in the pendant when it gets low?**

**R. Although the battery inside the compartment looks like a standard battery, it is specially sourced. Depending on the age of the pendant the battery connection may require soldering a new battery or clipping a new one in its place.**

### Technical Specifications:

- 1.2 meters long power cable
- Silicon feet for non slip base
- Red Power LED
- 75 mm x 75 mm x 35 mm
- 5 volt 1 Ah power
- White in colour

Smart Caller Safe Life  
5/ 270 Lower Dandenong Rd Mordialloc Vic  
3195  
PH: +61 3 9588 0833  
E: sales@safelife.com.au